


# Laser 2 Shear Head



# Laser 2 Shear Head

Item	Part No.	Description
1	258-36500	Body Assembly 240V
	258-36510	Body Assembly 110V <i>(not shown)</i>
2	258-32260	Assembly of Parts 20 - 23 & 26 - 32
3	258-32540	Assembly of Parts 9 - 11
4	258-32450	Assembly of Parts 13 - 18
5	258-30780	Screw M4 x 20mm
6	258-11740	Washer M4
7	249-15100	Tension Nut
8	249-00010	Sliding Sleeve
9	249-00020	Tension Lock Ring
10	249-15030	Lid Bush
11	258-32300	Top Casing
12	258-32310	Tension Pin
13	258-32340	Tension Pin Retainer
14	258-32230	Fork Body
15	249-10200	Prong RH Wide
16	249-10210	Prong LH Wide
17	258-32330	Prong Retainer
18	258-32800	Screw M3 x 5mm
19	157-00151	Crank Roller
20	258-32280	Crank Spindle
21	258-32420	Circlip
22	249-12250	Ball-race
23	258-32430	Circlip

Item	Part No.	Description
24	249-10510	Comb Screw
25	258-32440	Screw M4 x 20mm
26	258-32460	Shear Head Seal
27	258-32220	Gear
28	258-32250	Oil Seal
29	258-32240	Crank Spindle
30	258-32270	Intermediate Gear
31	258-32290	Main Body
32	258-32320	Fulcrum Post